### **Operating Instructions**

Correct useThe multi-function timers DMC with analogue time setting offer<br/>all the standard functions and time domains in one device.<br/>Moreover, DMC can be used as a sensor relay. A remote potenti-<br/>ometer connection is also available.DMC is intended for the control of time-sensitive processes at<br/>machineries and plants.Features• 16 functions: On-delay, signal off-delay, signal on- and<br/>off-delay, one shot actuation during starting, one shot<br/>actuation during stopping, wipe contact during starting<br/>and stopping, flicker, one shot actuation, pulse shaping,<br/>each in some cases inverted too, electronic sensor<br/>• 16 time ranges: 0.1-1 s; 0.3-3 s; 1-10 s; 3-30 s; 6-60 s;<br/>10-100 s; 0.3-3 mi; 1-20 min; 6-60 min;<br/>0.3-3 h; 0.6-6 h; 1.2-12 h; 2.4-24 h; 7.2-72 h; 16.8-168 h<br/>• 2 operating voltages: AC 230 V and DC 12-30 V



#### Time Ranges

Function

The requested time range is determined according to the following table using the selector switch 6-9. The time at the end position of the potentiometer t is given.

6789 15 <b>15 11 1</b>	605 6789 ON OFF	30min <b>5</b> 789	6789 12h - ON OFF
3s 🚛	100s	60min	24h
10s 🖬 🖬	3min	3h 💶	72h
30s	10min	6h 🛄	168h

#### Functions

The functions "signal off-delay", "signal on- and off-delay", "wipe contact during stopping", "one shot actuation during starting and stopping", "pulse shaping" are controlled via a potential-free contact at Y1-Y2.

Every change of state at Y1-Y2 directly affects the connected time function irrespective of whether a preceding reset time has elapsed or not. All other time functions start when the operating voltage is applied.

Compilation of the functions see page 2.

Functions and time ranges cannot be altered once the operating voltage has been applied.

#### Special Function: Electronic Sensor

With the "electronic sensor" function the relay picks up if the value of an electrical resistance connected to terminals Z1-Z2 drops below a certain level. The DMC can be used as a contact protection relay, sensor switching amplifier, temperature probe (with external PTC/NTC resistor) or twilight switch (with external LDR resistor) in this mode of operation.

#### Contacts

The devices have two change-over contacts. The second contact can be optionally switched as a time closing or instantaneous contact (switch 1):



Safety Precautions

- Ŵ
- The installation and operation must be carried out by qualified personnel only,
- who is familiar with the professional handling of machine equipment,
- who is familiar with the valid rules of industrial safety and accident prevention,
- who read and understood the operating instructions.
- The safe function of the device during machine operation cannot be guaranteed in case of wrong connection or improper operation. This may lead to fatal injuries.
- Pay attention to country specific regulations.
- The electrical installation must be performed after disconnecting the device and the machine from the mains supply.

Non-observance of the instructions above will cause the loss of warranty.

- The wiring must be carried out according to the instructions of this operating manual.
- The person who programs the device must be protected against electrostatic discharge (ESD protection).
- Opening the device, any manipulation of the device and the avoidance of the safety facilities are not permitted.
- All relevant safety regulations and standards must be attended to.
  Non-observance of the safety regulations may cause
- death, severe injuries or substantial damage to property.
- Before use, please, read the operating instructions and keep it in a safe place. Make sure that the operating instructions are always available for installation, initial operation and maintenance.

1

### **Operating Instructions**

Functions and Applications

## On-delay

Contact 15-16 (25-26) switches after operating voltage is applied to A1-A2 (or B1-B2) and time lapse to 15 -18 (25-28).



#### One shot actuation (starting)

Contact 15-16 (25-26) switches after operating voltage is applied to A1-A2 (or B1-B2) for the duration of the set time to 15-18 (25-28).



#### Flicker

When voltage is applied to A1-A2 (B1-B2) the timed contact turns on and off repeatedly, starting with the pause time.



The function can be inverted with switch 2 = ON (start with working time).

#### One shot actuation

Contact 15-16 (25-26) switches after operating voltage is applied to A1-A2 (or B1-B2) and time lapse t for 0.5 sec. to 15-18 (25-28).



The function can be inverted with switch 2 = ON.

#### Signal off-delay

Contact 15-16 (25-26) switches after the potential-free contact closes at Y1-Y2 to 15-18 (25-28). When Y1-Y2 opens the off-delay time t starts, after which the contact switches back to 15-16 (25-26).

2 3 4 5 ON OFF	A1-A2	
	Y1-Y2	
	15-18 (25-28)	
	(23-20)	L L

The function can be inverted with switch 2 = ON.

#### Signal on- and off-delay

If Y1-Y2 is connected via a potential-free contact, contact 15-16 (25-26) switches on expiry of t to 15-18 (25-28). When Y1-Y2 opens the time lapse t starts the off-delay, after which the contact switches back to 15-16 (25-26).

2 3 4 5 ON OFF	A1-A2 Y1-Y2 15-18 (25-28)		t.	t	<b></b>
	(23-20)		<b>t</b> ⇒	t	*
The function can be inverted with switch 2 = ON.					



#### One shot actuation (stopping)

If the closed potential-free contact at Y1-Y2 is opened, contact 15-16 (25-26) switches to 15-18 (25-28) for the duration t.



The function can be inverted with switch 2 = ON.

# One shot actuation during starting and stopping

Contact 15-16 (25-26) switches to 15-18 (25-28) for the time t after the potential-free contact closes at Y1-Y2. Once Y1-Y2 opens the contact 15-16 (25-26) for the duration t.



#### Pulse shaping

Contact 15-16 (25-26) switches to 15-18 (25-28) for the duration t when the potential-free contact closes at Y1-Y2 irrespective of whether the potential-free contact is opened before or after expiry of the time t.

2345	A1-A2	
ON ON	Y1-Y2	
OFF		
	15-18	
	(23-20)	

The function can be inverted with switch 2 = ON.



N12 E61-267-00

According to EN 60204-1 the unit is designed to be used in switch cabinets with a minimum environmental protection of IP54. The housing is designed to be mounted on a 35 mm DIN-rail according to DIN EN 60715 TH35.

### **Operating Instructions**

Installation

N12 E61-267-00

Electrical connection	<ul> <li>Select function and time range at the DIL switch on the side of the device bevore applying operating voltage.</li> <li>A1-A2 are operating voltage connections for AC 230 V, B1-B2 for DC 12-30 V.</li> <li>If the DC 12-30 V version is used, a control transformer according to EN 61558-2-6 or a power supply unit with electrical isolation from the mains must be connected.</li> <li>External fusing of the contacts (6A slow-blow or 8 A quick-action) must be provided.</li> <li>The line cross section must not exceed 2.5 mm<sup>2</sup></li> <li>If the device does not function after commissioning, it must be returned to the manufacturer unopened. Ope-</li> </ul>	A1151618A1151618Y1B1B1A2:Power supply AC 230 VA2:Power supply AC 230 VB1:Power supply DC 12-30 VB2:Power supply DC 12-30 VB2:Control line time functionY2:Control line time functionY2:Control line remote potiControl line remote poti25-26-28: Contact 1Contact 125-26-28: Contact 2	
	ning the device will void the warranty.	Z1         Z2         Y2         B2           25         26         28         A2	
Maintenance	The device must be checked once per month for proper function and for signs of tampering.	The device is otherwise maintenance free, provided that it was installed properly.	
Remote potentiometer	The remote potentiometer DFP 100 kOhm is available as an accessory with rotary knob, scale and mounting kit. If a remote potentiometer is connected the bridge between terminals Z1-Z2 must be removed and the potentiometer on the front set to maximum.	Remote Potentiometer DFP	
Techn. Data	Operating voltage	AC 230 V, 50-60 Hz and DC 12-30 V	
	Residual ripple	+ / - 10%	
	Power consumption	AC 3.5 VA, DC < 3 W	
	LEDS	yellow: stand by	
	Drotaction		
	Time ranges	0.1-1 s; 0.3-3 s; 1-10 s; 3-30 s; 6-60 s; 10-100 s; 0.3-3 min; 1-10 min; 3-30 min; 6-60 min; 0.3-2 b; 0.5 5 b; 1.2 12 b; 2.4 24 b; 7.2 72 b; 16.8 168 b;	
	Input resistance sensor relay	5.40 kOhm	
	Repeat accuracy	+/- 0.5%	
	Reclose readiness	< 60 ms	
	Switching canacity	AC 250 V: max 8 A max 2000 V/A	
		DC: 2 A at 24 VDC	
	Contact fuese		
	Contact fuses	b A slow-blow or 8 A quick-action	
	max. line cross section	2.5 mm <sup>-</sup>	
	Test voltage		
	Dielectric strength, leakage path/air gap	4 KV (DIN VDE 0110-1)	
		$-20^{\circ}\text{C} - +60^{\circ}\text{C} (dew_free)$	
	Weight	-20 C - +00 C (uew-liee)	
	Installation position	approx. 200 g	
		ary, Divital mounting	





T

Installation / removal

### **Operating Instructions**





N12 E61-267-00